

Notes:

- 1) All branches to be wrapped in Tesa 51036 tape
 2) All braches with connector leave 1' of wire exposed before connector
 3) All splices ("S") to be soldered or sonic welded and covered in 2" of adhesive heatshrink
 4) * Leave 6' exposed on T1, T2, T3, T4, T5, AND W17

