


## INDOT 2020 PTO HARNESS DIAGRAM



Notes:  
 \* Wire Colors and connections may vary with PTO harnesses supplied by other manufacturers  
 \*\* Clutch shift PTO requires connection to Allison "PTO Enable Input" circuit on Allison Gen. 4 and later controls.  
 Contact Muncie Power or Allison for more details.  
 Check with the vehicle dealer or body builder's information for location.

