




OMNI-SYSTEM™ DIAGRAM



PORT DESIGNATIONS	
PLA	FLOW UP
PLB	FLOW DOWN
PAA	FLOW LEFT
PAB	FLOW RIGHT
HA	HOIST UP
HB	HOIST DOWN
P	PUMP
T	TANK
LS	LOAD SENSE
B	AUG REVERSE
Z'	RETURN / CONNECT TO TANK

SP - MANUAL OVERRIDES
 UP POSITION = ENGAGED
 DN POSITION = DISENGAGED