


# TG SERIES SEAL KIT OR REBUILD KIT


## FOR UNITS WITH DIRECT MOUNT PUMP FLANGE

Examine the under side of the hydraulic mounting flange. If there is an o-ring groove as shown then use the o-ring 12T36751 provided in the kit. If groove is not present, then use the 2nd gasket provided (13T38542).

Lubricate seals and o-rings prior to installation. Place the o-ring around the output shaft bearing which protrudes from the housing before installing the output flange.



**NO GROOVE IN FLANGE**  
[USE 13T38542 GASKET]



**GROOVE FOR O-RING**  
[USE 12T36751 O-RING]



**Muncie®  
Power  
Products**

IN04-02 Printed in the U.S.A.  
© Muncie Power Products, Inc. 2004

**Muncie Power Products, Inc.** Member of the Interpump Hydraulics Group  
General Offices and Distribution Center • P.O. Box 548 • Muncie, IN 47308-0548  
(765) 284-7721 • FAX (765) 284-6991 • E-mail [info@munciepower.com](mailto:info@munciepower.com)  
Web site <http://www.munciepower.com>

Drive Products, Exclusive Agents for Canada, ISO Certified by an Accredited Registrar